T-Series NTP Network Time Server

Updating T-Series Firmware By Re-Flashing The File System

Models Covered: T100, T300, T550

Document Number: T1330-01 15-Oct-20

The latest version of this user guide can be obtained from TimeToolsLtd.com

Re-Flashing T-Series NTP Servers

Most T-Series firmware updates are provided as files that apply patches to the file system. However, periodically, major updates require replacing the boot-loader, kernel and file system.

The major firmware updates require that the T-Series memory be re-flashed from a USB flash drive. The updates have an incremented major revision number. e.g. $\underline{2}$.0.001.

This article describes how to re-flash T-Series NTP servers with the latest firmware using a FAT formatted USB flash drive.

Prerequisites

- Windows PC with RS232 serial port or USB to serial adapter.
- Serial console cable (supplied with T-Series unit) or RS232 null modem cable for PC to PC communication.
- Windows dumb terminal emulator, e.g. PuTTY or Hyper-terminal.
- A FAT formatted USB flash drive with at least 1 GB of free space.

Preparation

1. Establish Serial Communication Between PC and T-Series NTP Server.

Power down and isolate the T-Series from any networks by disconnecting network cables to the device.

Use the supplied serial console cable (RS232 null modem cable) to connect T-Series console port to PC RS232 COM port.

Open Windows dumb terminal emulator to communicate with serial COM port with the following settings:

115200 baud, 8 data bits, 1 stop bit, no parity, no flow control.

2. Prepare A USB Flash Drive.

Prepare a USB flash drive with a FAT formatted primary partition with at least 1 GB of free space.

See "Creating a FAT Formatted USB Flash Drive" below.

3. Download Binary Image.

Download required binary image update file from:

https://timetoolsltd.com/support/download/t-series-firmware/

Ensure that the image model matches the T-Series model that is being updated. e.g. T100, T300, T550.

The binary image file name has the following format: image-<device>-<version>.zip

e.g.: image-t100-20001.zip image-t300-20001.zip image-t550-20001.zip



4. Verify the Downloaded Image File.

Check the validity of the downloaded image by comparing the MD5 checksum of the file against the published checksum on the web page.

In Windows 10, the MD5 checksum of a file can be obtained using the 'CertUtil' command. The command has the following format:

CertUtil -hashfile <path-to-file> MD5

Example:

```
C:\>
C:\>
CertUtil -hashfile image-t100-20001.zip MD5
MD5 hash of image-t100-20001.zip:
a5710ec0a263f1182a45661a8ae26f06
CertUtil: -hashfile command completed successfully.
C:\>
```

5. Unzip Image to USB Flash Drive

Unzip downloaded image file to root directory of prepared FAT formatted USB flash drive.

F Home Share View H S V W Medium icons mane ▼ Panes Lay	Manage Drive Tools JD Large icons Small icons Details yout	MYVOLUME (D:)	ow/ de •	× ^ ¶
\leftrightarrow \rightarrow \checkmark \uparrow \blacksquare > MYVOLUME ((D:)		ٽ ~	
Name	Date m	odified	Туре	Size
colibri_vf	24/09/2	2020 12:01	File folder	
📮 flash_blk.img	23/09/2	2020 16:15	WinZip File	1 KB
🖳 flash_eth.img	23/09/2	2020 16:15	WinZip File	1 KB
💷 flash_mmc.img	23/09/2	2020 16:15	WinZip File	1 KB
4 items				

When correctly unzipped, a folder and 3 files will be present on the USB flash drive:

Folder	colib	ri_vf
File:	flash_	blk.img
File:	flash	eth.img
File:	flash	_mmc.img



Re-Flashing T-Series Firmware.

T-Series firmware is updated in two parts:

- U-Boot boot loader.
- File system.



WARNING: After re-flashing, the device will revert to default configuration.



WARNING: Do not power-off the unit when it is updating. Wait until it has finished!

Update the T-Series firmware by re-flashing the device as follows:

1. Enter Boot Loader

Power up the T-Series device.

Within 1 second of powering up, press the space bar on the PC dumb terminal emulator.

The device will enter the boot loader U-Boot. The boot loader prompt 'Colibri VFxx #' should be visible:

```
U-Boot 2015.04+fslc+gb66337d (Jan 18 2016 - 19:49:13)
.....
Model: Toradex Colibri VF50 128MB V1.2B, Serial# 08466601
Net: FEC
Hit any key to stop autoboot: 0
Colibri VFxx #
```

2. Update Boot Loader

Insert prepared USB flash drive into front panel of T-Series unit.

At the dumb terminal emulator, update the boot loader by running the 'setupdate' and 'update_uboot' scripts and resetting the device, as follows:

Colibri VFxx # Colibri VFxx # **run setupdate**



```
Colibri VFxx # run update_uboot
.....
Colibri VFxx # reset
resetting ...
```

Within 1 second of rebooting, press the space bar on the PC dumb terminal emulator to re-enter the boot loader.



INFORMATION: If the space key is not pressed in time to enter the boot loader, simply power the device off and back on and retry.

The U-Boot prompt 'Colibri VFxx #' should be visible.

Check the U-Boot version to ensure that the boot loader update has completed correctly.

```
<u>U-Boot 2016.11-2.8.6</u>+g83a53c1 (Jul 14 2020 - 10:25:54 +0000)
.....
Model: Toradex Colibri VF50 128MB V1.2B, Serial# 08466601
Net: FEC
Hit any key to stop autoboot: 0
Colibri VFxx #
```

3. Update Flash File System

Once the boot loader has been successfully updated, the flash file system can be updated.

Run the 'setupdate' and 'update' scripts as follows:

```
Colibri VFxx #
Colibri VFxx # run setupdate
.....
Colibri VFxx # run update
.....
resetting ...
```

When the 'update' script has completed, the device will automatically reboot.

The login prompt will be shown:

```
The Angstrom Distribution NTP001 ttyLP0
Angstrom v2017.12 - Kernel
Colibri-VF_Console-Image 2.8b6 20200908
NTP001 login: admin
Password:
```



4. Check Update.

Login to the device using the user name 'admin' and default password 'admin'.

Use the 'nts status' command to check the model and firmware build, to ensure that the update has completed successfully:

```
admin@NTP001:~$ nts status
.....
Model: <u>T300</u>
Firmware Build: <u>Rev. 2.0.001 13-OCT-20</u>
.....
```

The update is now complete.

The unit can be configured as required.



Appendix A: Creating a FAT Formatted USB Flash Drive

To update T-Series firmware requires a FAT formatted USB flash drive with at least 1 GB of free space. A FAT formatted primary partition can be created on a USB flash drive using Windows 10 Disk Manager. The new FAT primary partition must be the first partition on the drive.



WARNING: This process will erase the contents of the USB flash drive.

Insert the flash drive into a USB port on a Windows 10 PC.

Open Disk Manager.

Delete any non-FAT partitions by right-clicking on the flash drive partition and clicking "Delete Volume".

📅 Disk Manageme	ent						_	×
<u>F</u> ile <u>A</u> ction <u>V</u> ie	w <u>H</u> elp							
🗢 🄿 📰 👔	🖬 🗩 🗙 🗹	1 🔒 🦻	¥2					
Volume	Layout	Туре	File System	Status	Capacity	Free Spa	% Free	
🛲 (Disk 0 partition 4	4) Simple	Basic		Healthy (R	101 MB	101 MB	100 %	
HP_RECOVERY (E	:) Simple	Basic	NTFS	Healthy (P	13.40 GB	1.51 GB	11 %	
🛲 MyVolume (M:)	Simple	Basic	NTFS	Healthy (P	28.87 GB	28.80 GB	100 %	
- OS (C:)	Simple	Basic	NTFS	Healthy (B	452.16 GB	196.72 GB	44 %	
SYSTEM	Simple	Basic	NTFS	Healthy (S	100 MB	59 MB	59 %	
= Disk 1								^
Removable (G:)								
No Media								
= Dick 2								
Removable	MyVolume (M·)					///////////////////////////////////////		
28.87 GB	28.87 GB NTES							
Online	Healthy (Primary	Partition)						
		<u> </u>		<u> </u>		//////////////////////////////////////		
								~
Unallocated 📕 P	rimary partition							Ť



Right click on the unallocated drive and click "New Simple Volume..." to run the new simple volume wizard:



Create a partition of at least 100 MB:

New Simple Volume Wizard	×							
Specify Volume Size Choose a volume size that is between the maximum and minimum sizes.								
Maximum disk space in MB:	29563							
Minimum disk space in MB:	8							
<u>S</u> imple volume size in MB:	29563							
	< <u>B</u> ack <u>N</u> ext > Cancel							



 $\ensuremath{\textcircled{}^{\circ}}$ 2020 TimeTools Limited. All Rights Reserved.

Click 'Format this volume with the following settings:'.

Enter a volume label and select 'Format as FAT32'.

New Simple Volume Wizard							
Format Partition To store data on this partition, you must format it first.							
Choose whether you want to forma	t this volume, and if so, what settings you want to use.						
O Do not format this volume							
Format this volume with the f	ollowing settings:						
<u>File</u> system:	FAT32 ~						
<u>A</u> llocation unit size:	Default ~						
<u>V</u> olume label:	MyVolume						
Perform a quick format	:						
Enable file and folder compression							
	< Back Next > Cancel						

When formatting is complete the USB flash drive should have a Healthy FAT32 Primary Partition:

📅 Disk Managemen	t						-	\times
<u>File</u> <u>Action</u> <u>V</u> iew	<u>H</u> elp							
🗢 🄿 🖬 👔 🗖	1 🗩 🏹 📼]						
Volume	Layout	Туре	File System	Status	Capacity	Free Spa	% Free	
🛲 (Disk 0 partition 4)	Simple	Basic		Healthy (R	101 MB	101 MB	100 %	
HP_RECOVERY (E:)	Simple	Basic	NTFS	Healthy (P	13.40 GB	1.51 GB	11 %	
MYVOLUME (H:)	Simple	Basic	FAT32	Healthy (P	28.85 GB	28.85 GB	100 %	
💳 OS (C:)	Simple	Basic	NTFS	Healthy (B	452.16 GB	196.72 GB	44 %	
SYSTEM	Simple	Basic	NTFS	Healthy (S	100 MB	59 MB	59 %	
= Disk 1								^
Removable (G)								
Kentovable (0.)								
No Media								
							1	
- Disk 2								
Removable N	IYVOLUME (H:)						
28.87 GB 2	8.87 GB FAT32							
Online	lealthy (Primary	Partition)						
								~
📕 Unallocated 📕 Pri	mary partition							



Appendix B: Serial Console Cable (RS232 Null Modem)

A serial console cable is required to re-flash the T-Series.

One is supplied with all T-series models.

The cable is a RS232 null modem cable with DB9 female connectors used for PC to PC communication.



A null-modem cable is wired as follows:

pin 2 ...to... pin 3 pin 3 ...to... pin 2 pin 4 ...to... pin 6 pin 5 ...to... pin 5 pin 6 ...to... pin 4 pin 7 ...to... pin 8 pin 8 ...to... pin 7

Appendix C: Troubleshooting

No PC To T-Series Serial Communications

- Ensure that the TimeTools supplied serial console cable or compatible cable is being used.
- Check the serial cable connection between PC serial port and T-Series console port.
- Check PC dumb terminal emulator communications settings.

File System Does Not Update

- Ensure USB flash drives primary partition is formatted to FAT32.
- The partition must be the first partition on the drive.
- Check the validity of the downloaded image file with MD5 checksum.
- Ensure that downloaded image file has been correctly unzipped to the USB flash drive.
- Ensure that boot-loader has been correctly updated before updating the flash file system.



 $\ensuremath{\mathbb{C}}$ 2020 TimeTools Limited. All Rights Reserved.

While reasonable efforts have been taken in the preparation of this document to ensure its accuracy, TimeTools Limited assumes no liability resulting from any errors or omissions in this manual, or from the use of the information contained herein.

All claims based on information publicly available at time of printing.

All product or service names mentioned in this document are trademarks of the companies with which they are associated.

